

1. Disconnect +ve battery terminal and drain water system . Remove the original fans & shroud.
2. Assemble the two fans on the shroud using the M6 bolt kits with the head facing the radiator core side.
3. Mount the shroud and fans to the radiator as shown (Fig 1) using the original shroud mounting points.
4. With reference to (Fig 2) connect the cooling fans in parallel.
5. Follow the Electronic fan controller fitting and setup instructions (Supplied in the Kit)

Fig 1



Fig 2

